



Vestax Mixing Controller

# VMC-004FXu

**取扱説明書**

P.2~

**OWNER'S MANUAL**

P.14~

〒154-0023

東京都世田谷区若林1-18-6

電話 03-3412-7011 ファックス 03-3412-7013

Web : [www.vestax.com](http://www.vestax.com)

Vestax Corporation

1-18-6 Wakabayashi, Setagaya-ku, Tokyo 154-0023 Japan

Phone 03-3412-7011 Fax 03-3412-7013

Web : [www.vestax.com](http://www.vestax.com)

Vestax Europe Technical Support

Rheinstr.213 D-53332 Bornheim Germany

Phone 49(0)2222-95-23-72 Fax 49(0)2222-95-23-74

# CONGRATULATIONS !

Thank you for purchasing the Vestax VMC-004FXu Mixing Controller. We suggest that you read through this owner's manual thoroughly so that you may enjoy the full use of this product safely and in the knowledge of all its special features and suitable applications.

## CONTENTS

|                                    |    |
|------------------------------------|----|
| C A U T I O N .....                | 14 |
| IMPORTANT SAFEGUARDS .....         | 15 |
| F E A T U R E S .....              | 16 |
| CONTROLS AND FUNCTIONS .....       | 17 |
| T O P   P A N E L .....            | 17 |
| F R O N T   P A N E L .....        | 18 |
| R E A R   P A N E L .....          | 19 |
| ABOUT THE EFFECTS .....            | 20 |
| HOW TO CHANGE THE FADER UNIT ..... | 25 |
| CONNECTION DIAGRAM .....           | 26 |
| S P E C I F I C A T I O N S .....  | 27 |



### CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK  
DO NOT REMOVE COVER (OR BACK)  
NO USER-SERVICEABLE PARTS INSIDE  
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT  
EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

# IMPORTANT SAFEGUARDS

## READ BEFORE OPERATING EQUIPMENT

This product was designed and manufactured to meet strict quality and safety standards. There are, however, some installation and operation precautions which you should be particularly aware of.

1. Read instructions-All the safety and operating instructions should be read before the appliance is operated.
2. Retain instructions-The safety and operating instructions should be retained for future reference.
3. Heed Warnings-All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow Instructions-All operating and use instructions should be followed.
5. Cleaning-Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. Attachments-Do not use attachments not recommended by the product manufacturer as they may cause hazards.
7. Water and Moisture-Do not use this product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.
8. Accessories-Do not place this product on an unstable cart, stand, tripod, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
9. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
10. Power sources-This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company.
11. Lightning-For added protection of this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the product due to lightning and power-line surges.
12. Overloading-Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.
13. Object and Liquid Entry-Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
14. Servicing-Do not attempt to service product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified personnel.

15. **Damage Requiring Service**-Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
- a. When the power-supply cord or plug is damaged.
  - b. If liquid has been spilled or objects have fallen into the product.
  - c. If the product has been exposed to rain or water.
  - d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
  - e. If the product has been dropped or cabinet has been damaged.
  - f. When the product exhibits a distinct change in performance this indicates need for service.
16. **Replacement Parts**-When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original parts. Unauthorized substitutions may result in fire, electric shock or other hazards.
17. **Safety Check**-Upon completion of any service or repairs to product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
18. **Carts and Stands**-The appliance should be used only with a cart stand that is recommended by manufacturer.
19. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.




## FEATURES

- Effects are assignable separately to the master section and A & B side of the crossfader. Easily selectable with the effect assign switch.
- A High-grade 24bit/96kHz Digital Sound Processor (DSP) has been applied to the VMC-004FXu for better sound quality and less latency.
- Digital connection with computers and USB devices is enabled by installing TUB-1(USB Board / Sold Separately)to the OPTION BOARD slot.
- Original algorithm developed so that each effect parameter is adjustable with simple operation.
- The TAP button is used to set the delay time and LFO rate, simply by tapping the button. The inputted tempo can be switched to 1/4, 1/2, 3/4 and double of the original tempo instantly with the beat select switches.

# CONTROLS AND FUNCTIONS

## TOP PANEL



### ① INPUT SELECTOR

Used to select the signal (LINE or PHONO) to be sent to each PGM channel. The upper most position will select PHONO input. This selector switch can also be used to perform for TRANSFORMER SCRATCH.

※When 2 individual inputs are connected to LINE 5 and USB(Optional, please read REAR PANEL on page19) and if the input select switch of PGM 3 is set to LINE 5/USB, both signals will be mixed in to the channel.

### ② TRIM VOLUME

Adjusts the input level of each channel. For optional acoustic quality, set the INPUT LEVEL VOLUME to a position of 7 or 8 then; adjust the TRIM so that a sufficient signal is fed through the channel without distorting.

### ③ ISOLATOR HI

Adjusts the HI frequency level of each PGM.

### ④ ISOLATOR MID

Adjusts the MID frequency level of each PGM.

### ⑤ ISOLATOR LOW

Adjusts the LOW frequency level of each PGM.

### ⑥ C.F. ASSIGN SWITCH

Assigns the signals from each of the PGM channels to either side of the crossfader and to OUTPUTS as well. There are three positions;  
A...The PGM is sent to the "A" position or left position of the crossfader.

MASTER...The PGM is sent directly to the OUTPUTS.

B...The PGM is sent to the "B" position or right side of the crossfader.

### ⑦ INPUT LEVEL FADER

Used to adjust the input level of each PGM channel.

### ⑧ INPUT LEVEL METER

The LED level meters indicate the input signal level of each PGM channel.

### ⑨ CROSS FADER

When the input level of PGM1 and PGM2 are properly set, PGM1 will be heard with the crossfader set to the left side. PGM2 will be heard with the cross fader set to the right side. When the crossfader is set in the center, both programs will be heard. This fader is detachable for easy replacement with "CF-R US" when it is worn out.

### ⑩ MASTER 1 LEVEL VOLUME

Adjusts the signal level outputs from MASTER 1 OUTPUT JACKS ⑤⑥③⑧.

### ⑪ MASTER 2 LEVEL VOLUME

Adjusts the signal level outputs from MASTER 1 OUTPUT JACKS ⑦⑧.

### ⑫ MASTER LEVEL METER

The LED level meters indicate the master① signal level of each PGM channel.

### ⑬ POWER INDICATOR

Lights up when the POWER SWITCH ⑩ is on.

#### ⑭ CUE CHANNEL SELECT SWITCH

This switch is used to select which program channel 1-4 is heard in headphones connected to the mixer.

#### ⑮ MONITOR MIX VOLUME

This volume is used to select which type of monitor signal, either CUE or MASTER, is heard in headphones connected to the mixer. When set to CUE, signals from PGM channel selected by CUE CHANNEL SELECT SWITCH⑭ will be heard. When set to MASTER, signals from OUTPUT will be heard. Signals are mixed as volume knob is turned.

#### ⑯ MONITOR LEVEL VOLUME

Adjusts the headphone monitor level.

#### ⑰ PHONE JACK

Connect the headphones with the impedance of 8ohm to 600ohm

#### ⑱ Effect assign

This switch selects the sound source to have effects added to. The assign section is selectable from the A & B side of the crossfader and the Master sound.

#### ⑲ Effect select

This switch selects the type of effect you wish to use.

#### ⑳ Rate/time volume

This volume adjusts the rate/time of each effect.

#### ㉑ Depth/sweep volume

This volume adjusts the depth/sweep of each effect.

#### ㉒ Effect on/off indicator

This indicator lights up when the effector is ON.

#### ㉓ Effect on/off button

This button turns the effector on ON/OFF.

#### ㉔ Beat select indicator

This indicator indicates the selected beat button.

#### ㉕ Beat select button

This button changes each effect tempo set with the TAP button or rate/time volume to 1/4, 1/2, 3/4, 1 and 2 of the original tempo.


#### ㉖ TAP button

The rhythm of when this button is pushed for more than 2 times becomes the BPM of the "1" button.

#### ㉗ TAP indicator

This indicator flashes on and off and shows BPM which set.

### FRONT PANEL




#### ㉘ C.F. CURVE SELECT SWITCH

Adjusts the crossfader curve. Setting to the right side gives a steep crossfader good for scratching and cutting, whereas, setting to the left side gives a gentle crossfader good for long running mixes.

#### ㉙ OPTION BOARD INSERT

## REAR PANEL



### 30 POWER SWITCH

Used to turn power on. When you operate this switch, make it sure that the volume of the connected powered amplifier is how enough or the main switch of amplifier is turned off. If you use other adaptor, may cause damage to the mixer.

### 31 POWER IN JACK

Connect the Vestax AC-14 an exclusive, AC adaptor.

### 32 LINE INPUT JACK

Connect the equipment with line level output (-10dB or 0dB), such as CD players, tape decks, DATs, MDs, etc. The signal from line level equipment is fed to the PGM channels when Line input is selected.

### 33 PHONO INPUT JACK

Connect turntables equipped with MM (Moving Magnet type) cartridge. The signal from the turntable is fed to the PGM channels when Phono input is selected.

### 34 GROUND TERMINAL

Connect this terminal to the ground lead of the turntables.

### 35 MIC INPUT JACK

Input jack for MIC. Corresponds to  $\phi$  6.3 standard stereo plug.

### 36 MASTER 1 OUTPUT JACK [RCA PIN JACK]

Output connection for MASTER 1 LEVEL volume. Connect to INPUT on the power amplifier. (Connect to AUX or LINE if using an Audio amplifier.)

### 37 MASTER 2 OUTPUT JACK [RCA PIN JACK]

Output connection for MASTER 2 LEVEL volume. Connect to INPUT on the power amplifier. (Connect to AUX or LINE if using an Audio amplifier.) This output can also be used for recording or monitoring the sound.

### 38 MASTER1 OUTPUT JACK [BALANCED XLR JACK: HOT=PIN2]

XLR output jack for signals from MASTER 1 LEVEL volume. Connect to INPUT on the power amplifier. (Connect to AUX or LINE if using an Audio amplifier.)

# ABOUT THE EFFECTS

## ① DELAY



This effect adds a delay sound to the original sound.  
Maximum delay time is 2.7seconds.

### ■ TAP button

The average tempo set by pushing the TAP button more than 2 times becomes the LFO cycle tempo.

### ■ Beat select button

"1/4" TEMPO= (A) × 1/4  
 "1/2" TEMPO= (A) × 1/2  
 "3/4" TEMPO= (A) × 3/4  
 "1" TEMPO= (A) × 1  
 "2" TEMPO= (A) × 2



## ② ECHO



This effect adds numerous delay sounds to the original sound.

### ■ TAP button

The average tempo set by pushing the TAP button more than 2 times becomes the LFO cycle tempo.

### ■ Beat select button

"1/4" TEMPO= (A) × 1/4  
 "1/2" TEMPO= (A) × 1/2  
 "3/4" TEMPO= (A) × 3/4  
 "1" TEMPO= (A) × 1  
 "2" TEMPO= (A) × 2





### ※HOLD

The echo repeating sound will repeat play in the rhythm of the TEMPO when the depth/sweep volume is set to HOLD. The TEMPO of the repeating sound can be set with rate/time volume and beat select button.

## ③ REVERB

This effect adds a reverberant sound to the original sound.





#### ④ FLANGER

This effect adds a time-shifted sound to the original sound.

##### ■ TAP button

The average tempo set by pushing the TAP button more than 2 times becomes the LFO cycle tempo.

##### ■ Beat select button


"1/4"  $\text{TEMPO} = (A) \times 1/4$

"1/2"  $\text{TEMPO} = (A) \times 1/2$

"3/4"  $\text{TEMPO} = (A) \times 3/4$

"1"  $\text{TEMPO} = (A) \times 1$

"2"  $\text{TEMPO} = (A) \times 2$




#### ※ Restarting the LFO

This feature restarts the LFO cycle to gain the same LFO effect when adjusting the depth/sweep volume and beat select button.


#### ⑤ RING MOD.

This effect modulates the original sound with sign wave patterns.



#### ⑥ PITCH SHIFTER

This effect changes the pitch of the original sound.



### ⑦ AUTO PAN

This effect changes the volume balance of left and right.

#### ■ TAP button

The average tempo set by pushing the TAP button more than 2 times becomes the LFO cycle tempo.

#### ■ Beat select button

"1/4" TEMPO= (A)  $\times 1/4$


"1/2" TEMPO= (A)  $\times 1/2$

"3/4" TEMPO= (A)  $\times 3/4$


"1" TEMPO= (A)  $\times 1$

"2" TEMPO= (A)  $\times 2$

rate/time VR




depth/sweep VR




### ⑧ VOCAL CANCEL

This effect affects the mid frequency and cuts out the vocal sound.

rate/time VR




depth/sweep VR




### ⑨ VOCODER

This effect changes the original sound to a robotic sound.

rate/time VR




depth/sweep VR




# ⑩ **LOW PASS FILTER (MANUAL)**

The Q changes with the rate/time volume. The depth/sweep volume adjusts the filter frequency.

rate/time VR




depth/sweep VR




# ⑪ **BAND PASS FILTER (MANUAL)**

The Q changes with the rate/time volume. The depth/sweep volume adjusts the filter frequency.

rate/time VR




depth/sweep VR




# ⑫ **HI PASS FILTER (MANUAL)**

The Q changes with the rate/time volume. The depth/sweep volume adjusts the filter frequency.

rate/time VR



depth/sweep VR



### ⑬ LOW PASS FILTER with LFO

### ⑭ BAND PASS FILTER with LFO

### ⑮ HI PASS FILTER with LFO

The filters frequency changes in the time cycle set with the rate/time volume and TAP button.

#### ■ TAP button

The average tempo set by pushing the TAP button more than 2 times becomes the LFO cycle tempo.

#### ■ Beat select button


"1/4" TEMPO= (A)  $\times$  1/4

"1/2" TEMPO= (A)  $\times$  1/2

"3/4" TEMPO= (A)  $\times$  3/4

"1" TEMPO= (A)  $\times$  1

"2" TEMPO= (A)  $\times$  2



#### ※ Restarting the LFO

This feature restarts the LFO cycle to gain the same LFO effect when adjusting the depth/sweep volume and beat select button.

### ⑯ PHASER

This effect adds different phases to the original sound.

#### ■ TAP button

The average tempo set by pushing the TAP button more than 2 times becomes the LFO cycle tempo.

#### ■ Beat select button


"1/4" TEMPO= (A)  $\times$  1/4

"1/2" TEMPO= (A)  $\times$  1/2

"3/4" TEMPO= (A)  $\times$  3/4

"1" TEMPO= (A)  $\times$  1

"2" TEMPO= (A)  $\times$  2



#### ※ Restarting the LFO

This feature restarts the LFO cycle to gain the same LFO effect when adjusting the depth/sweep volume and beat select button.

## HOW TO CHANGE THE FADER UNIT

### CAUTION

- When you change the fader, make it sure that the main switch is turned off. If not, may cause noise or short circuit.
- When you use the screwdriver, make it sure that you should choose the right side. Otherwise, may break screws.

### ■ HOW TO REMOVE THE TOP PANEL.

- ① Remove all fader knobs and the 4 screws. (see fig.A)
- ② Remove the top panel.




fig.A

### ■ HOW TO CHANGE THE FADER UNIT

- ① Remove the screws on the fader panel. (see fig.B)
- ② Remove the fader unit from the mixer.
- ③ Carefully remove the multi-cable connector from fader unit. (see fig.C)
- ④ Attach multi-cable connector to new fader unit.
- ⑤ Position the fader unit carefully and secure with screws.




fig.B

### ■ HOW TO REPLACE THE CF UNIT WITH "CF-PCV"

Please see fig.C for replacement of the fader. Place the fader unit in the proper position and fix it with two screws. (fig.D-b)

There is a switch for CF-PCV unit. When "CF-PCV" unit is installed, set the switch to "PCV" mode.





fig.C

### CAUTION

When the fader unit is replaced, do not loosen the screws with  marking.





fig.D


- Ⓐ: CF-RUS or CF-R  
Ⓑ: CF-PCV

# CONNECTION DIAGRAM [example]



# SPECIFICATIONS

| INPUT SECTION                                 |       | NOMINAL INPUT               | MAXIMUM INPUT      | IMPEDANCE |
|---|-------|-----------------------------|--------------------|-----------|
| MIC IN:PGM-1~2 (φ6.3 PHONE JACK / UNBALANCED) |       | -52dBv (2.5Vrms)            | -30dBv (32mVrms)   | 3.3kΩ     |
| PHONO IN:PGM-1~4 (RCA PIN JACK / UNBALANCED)  |       | -45dBv (5.6Vrms)            | -22dBv (80mVrms)   | 49kΩ      |
| LINE IN:PGM-1~4 (RCA PIN JACK / UNBALANCED)   |       | -4dBv (1.0V)                | +11dBv (70Vrms)    | 7kΩ       |
| OUTPUT SECTION                                |       | NOMINAL INPUT               | MAXIMUM INPUT      | IMPEDANCE |
| MASTER OUT:1~2 (RCA PIN JACK / UNBALANCED)    |       | 0dBv (1.0Vrms)              | +17.5dBv (7.5Vrms) | 220Ω      |
| PHONES (φ6.3 PHONE JACK)                      |       |                             | 100mW (47Ω102d)    | > 8Ω      |
| ISOLATER (PGM-1~4)                            | :HI   | 2.5kHz≤ / BOOST:+6dB        |                    | CUT:-∞    |
|   | :MID  | 250Hz ~ 2.5kHz / BOOST:+6dB |                    | CUT:-∞    |
|   | :LOW  | ≤250Hz / BOOST:+6dB         |                    | CUT:-∞    |
| FREQUENCY RESPONSE                            | :LINE | 20Hz ~ 20KHz ±3dB           |                    |           |
| S/N RATIO                                     | :LINE | 70dB≤                       |                    |           |
| CROSS TALK                                    | :C.F. | 65dB≤                       |                    |           |
|   | :PGM  | 65dB≤                       |                    |           |
| OTHER   |       |                             |                    |           |
| POWER SUPPLY                                  |       | AC-14, 1500mA               |                    |           |
| POWER REQUIREMENT                             |       | ≒20VA                       |                    |           |
| WEIGHT  |       | ≒4.5kg                      |                    |           |
| DIMENSIONS (W×H×D)                            |       | 264×105×260 (mm)            |                    |           |







mixing controller

**VMC-002XLu TUB**

**VMC-004XLu TUB**

**VMC-004FXu TUB**

## Supplemental Instruction Sheet

Vestax Corporation  
1-18-6 Wakabayashi, Setagaya-ku, Tokyo 154-0023 Japan  
Phone 03-3412-7011 Fax 03-3412-7013  
Web : [www.vestax.com](http://www.vestax.com)

Vestax Europe Technical Support  
Rheinstr.213 D-53332 Bornheim Germany  
Phone 49(0)2222-95-23-72 Fax 49(0)2222-95-23-74

Please be sure to completely read this supplemental instruction sheet along with the user's manual of the following products. (Products labeled "TUB")

- VMC-002XLu\_TUB
- VMC-004XLu\_TUB
- VMC-004FXu\_TUB

### ◇ HOW TO USE USB

Connect the mixers USB input/output port to a computers USB port with a USB cable.  
Sound Input/Output will be enabled simply by connecting via USB, using the OS internal driver.

※USB board features

- USB1.1(USB2.0 compatible) compliant
- USB BUS power operated

The USB POWER LED will light up after the mixer is identified by the computer and the power has been supplied.

### ◇ USB PORT CHANNEL ASSIGN

#### (1) VMC-002XLu TUB

⇒Please refer to (27) , page 13 of the VMC-002XLu users manual.

Assigned to:

INPUT: LINE2/USB of PGM2

OUTPUT: MASTER OUTPUT

#### (2) VMC-004XLu\_TUB

⇒Please refer to (20), page 13 of the VMC-004XLu users manual.

Assigned to:

INPUT: LINE4/USB of PGM4

OUTPUT: MASTER OUTPUT


#### (3) VMC-004FXu\_TUB

⇒Please refer to (29), page 18 of the VMC-004FXu users manual.

Assigned to:

INPUT: LINE5/USB of PGM3

OUTPUT: MASTER OUTPUT



## ◇ SYSTEM REQUIREMENTS

### Minimum System requirement

### ● OS(Operating System )

Windows:

Windows98/98SE/Me, 2000/XP

(Windows XP will require the latest USB audio driver available from Windows update website)

Macintosh:

- Mac OS X 9.1 and later versions
- Mac OS X 10.0 English Edition and later versions
- Mac OS X 10.1 Japanese Edition and later versions

(Mac OS X 10.0 Japanese Edition is NOT SUPPORTED)

All versions before OS X 9.1 is NOT SUPPORTED

### ※ NOTE

- The minimum system requirements above are for the mixer. If the minimum system requirement of the software is higher than the mixers requirement, please prepare an advanced operating system qualified.
- Macintosh CPU accelerator cards are not supported. The computer must have USB connection.
- YAMAHA AC-XG Audio Device does not work with this mixer.

\*Above are minimum requirements and does not guarantee performance for all computers and devices.

## ◇ USB connection confirmation

The USB POWER LED (red) will light up when the mixer is connected to a computer via USB and indicate that USB input/output is operating.

Please follow the instructions below to confirm if the computer has identified the mixer via USB connection.

Windows XP:

To check connection status in Windows XP, view [control panel] > [system] > [hardware] > [device manager] > inside [sound, video and game controller] find [USB Audio device] .

If both are displayed and the status is "This device is installed correctly", the mixer and computer is connected correctly.

Macintosh:

To check the connection status in Macintosh, view [Applications] > [Utilities] > [Audio MIDI setting] > [MIDI device] and find "Vestax PC-CONTROLLER". The property shall show,

- \* Device: Vestax PC CONTROLLER
- \* Manufacturer: Vestax
- \* Model: Vestax PC-CONTROLLER

The computer and the mixer are connected correctly if the information above is shown.